CloseUp® System User Guide Addendum

Your Heaven® Audio | December 2017

Thank you for purchasing the Your Heaven® Audio CloseUp® System! Based on your feedback, we are constantly improving our product and some of our most recent changes haven't made it into the printed manual yet. Here's what's new:

Hardware Improvements

On the "Getting Started Quick" card and the User Guide included with the CloseUp® System, the appearance of the Microphone (18) and Guitar Hole Cover (21) differs from the illustrations.

The 1/4" to XLR cable (7) has been replaced with a smaller 1/4" to XLR adapter and its location in the carrying case has been swapped with the Microphone Extension Cable (17).

New Microphone Attachment Method

The Guitar Microphone and Soundhole Cover for the CloseUp® System have been updated. Follow the instructions found here instead of those in the User Guide.

•• Fitting the Guitar Microphone & Sound Hole Cover for your personal guitar ••


The underside of the Sound Hole Cover has a diagonal wood and foam brace (1). This is what attaches the Sound Hole Cover to the inside edge of your guitar's sound hole. The Sound Hole Cover also has a small notch for the microphone wire.



(1)
Note direction of brace on the cover's backside.

Slide the microphone into your sound hole below the strings (2).

Continue sliding the Sound Hole Cover (wooden side up) underneath the strings (3).



Once you've pushed far enough, the other side of the cover should slide in as you press down the brace's upper edge (5).

Adjust as needed.



(2) Slide microphone below strings.



(3) Slide cover below strings.



(4)
Push lower edge of cover down and into guitar hole. Fit wire into notch.



(5) Near upper edge of brace, push in towards center, then down.

· Attaching the Guitar Strap to your guitar nut · ·

NOTE: For the next step, we recommend adjusting the wire snug against the back of the guitar to avoid it snagging on clothing, etc. This is shown in picture (6).

The microphone wire has a guitar end pin attachment. This strap can hold the microphone wire so it wraps around the backside of your guitar and out of your way. Simply insert the guitar end pin into the incision in the strap and adjust the microphone wire as needed (6).

· Removing the Sound Hole Cover & Guitar Microphone · ·

Press the top edge of the Sound Hole Cover in towards the center of the sound hole to release the tension of the brace (7).

Lift the top edge of the cover and pull it up towards you to remove it from beneath the guitar strings (8).

We are glad to help answer any questions. Please reach us at: $\underline{ support@yourheaven.net}$

Download the most recent software at: yourheaven.net/closeup-downloads



(6) Insert end pin into strap attachment.



(7)
Push cover in at top of brace. Then lift cover.



(8)
Slide cover towards you to remove.